



Installation Instructions

AQ-4100 Shower Filter

Warranty Registration

It is very important to complete and return the enclosed warranty registration form. By completing this form and returning it, you activate the 100 day replacement warranty, which covers defects in materials and workmanship.

“Pure Satisfaction”

All aquasana products offer a 60-day 100% money back guarantee. If for any reason you are not satisfied with your purchase, simply call us, for a return merchandise authorization number and a full refund will be promptly issued upon return.

The aquasana deluxe shower filtration system is designed to produce the highest quality water possible with the least amount of pressure loss. Aquasana’s patented two stage filter cartridge substantially reduces chlorine and other chemicals present in tap water.

In compliance with California State Law, this system has a maximum flow rate of 2.5 gallons per minute. The aquasana adjustable shower head can be adjusted to the desired pressure while still conserving water usage. The filter cartridge will filter up to 10,000 gallons of water and should be replaced every 6 months per instructions.

Water for Life.

Clean Water Made Easy.

Members of our Water for Life Program receive:

- Fresh cartridges delivered every 6 months
- A 20% discount and FREE shipping
- Exclusive member benefits and rewards
- An extended product warranty

For more information, call one of our Water for Life specialists.

866-662-6885



1. Unpack and Prepare Contents

Package contains:

- Filter system — which includes the upper filter body and threaded cartridge.
- Deluxe aquasana shower head
- Instructions and warranty
- Water for Life auto-ship form

Remove the black plastic shipping plugs from the inlet and outlet of the filter system and make sure the white rubber washer is in place in the chrome inlet collar.

2. Shower Head Removal

Remove your existing shower head from the shower supply pipe.

3. Filter Attachment

Attach the filter system to the supply pipe as shown in **Figure 1**. While holding the shower filter in a stationary position, thread the chrome inlet collar onto the supply pipe by turning clockwise. Tighten the connector finger tight, and then, using a pair of pliers, turn an additional 1/4 turn or until the filter system retains a firm position.

4. Filter Flush and Activation

- Place bucket or container under the filter system to capture the first 1-2 gallons of discolored water. (**Figure 2**)
- Turn on **cold** water. After the water has turned clear, adjust the temperature up to a normal shower temperature. There will be a slight delay in temperature adjustment due to the volume of water in the filter.
- Run water until clear and then turn off and back on several times. Repeat this procedure until the initial surge of water is free of discoloration.

5. Shower Head Attachment

Attach the shower head to the filter body as shown in **Figure 3**.

Now you are ready to enjoy the benefits of showering in healthy, chlorine free water!

For best results, use the dual-action shower head provided with this system.

Do NOT use a shower head or wand with a shut-off valve.

DO NOT OVERTIGHTEN THE CHROME INLET COLLAR

Overtightening may cause the washer to compress into the inside of the shower pipe, resulting in leakage around the connector. If this occurs, unscrew the chrome inlet collar from pipe, reinstall the washer and reconnect the shower pipe.



Figure 2

The initial surge of water will be discolored with carbon fines and may soil your shower stall. This carbonized water is beneficial to plants and the environment. It can be discarded in a plant bed or down the drain.




Figure 1




Figure 3